

Daikin Appliances Error Code Guide

A step-by-step guide on how to check and interpret error codes.

1. Using the Indoor Unit Display

- Look at the LED indicator on the indoor unit.
- If there is a malfunction, the LED will blink in a pattern (e.g., 3 times, pause, 2 times).
- The blinking sequence corresponds to an error code (like U4, L5, A3).
- Check your model's manual to interpret the blinking pattern.

2. Using the Remote Controller

Wireless Remote (handheld):

- Turn the remote off.
- Hold the Cancel button for about 5 seconds until '00' shows on the display.
- Use the temperature up/down buttons to scroll through codes.
- When the indoor unit beeps, that is the stored error code.

Wired Remote (wall-mounted):

- Press the Menu or Check button (depends on model).
- Navigate to Error Code or Malfunction History.
- The error code (e.g., E7, H0) will be shown on screen.

3. Using Daikin Service Checker or App

- Technicians can use the Daikin Service Checker tool to connect to the system and read error codes.
- Some newer units support Daikin mobile apps (Daikin Comfort Control, Daikin One+) that may display fault codes.

4. Outdoor Unit (Multi-split / VRV / VRF systems)

- Outdoor units may have a 7-segment LED display on the PCB inside the unit.

- The code will be displayed directly (e.g., U4 = communication error).
- Requires opening the unit panel (usually for technicians).

■ Tip:

Once you find the error code, look it up in the service manual or Daikin's error code list for troubleshooting steps.

Example Error Codes

Code	Meaning
U4	Communication error
L5	Overcurrent on compressor
A3	Drain level error